

FEATURES:

- made from 7/64" thick steel
- screwed into underside of desk top and recess cut into top of apron or side
- holes are countersunk for screwheads on opposite sides
- supplied with #6 x 5/8 flat head screws
- figure 8 shaped
- 12" spacing recommended

APPLICATION:

This fastener is used to attach desk tops or table tops.

SPECIFICATIONS:

INSTALLATION:

1. Cut rabbet cut into apron approximately one every 12".
2. Drill pilot holes and attach fastener to apron.
3. Lay desk top upside down on flat surface. Turn desk upside down on top and position in place.
4. Drill pilot holes and attach fastener to underside of desk top.

