



For use only on boxes or cabinets with a 3/4" thick back.

1. Using the support or the reference dimensions shown, mark screw locations on the box or cabinet side and lid back.
2. Drill stopped pilot holes and mount the support to the box.
3. Drill pilot holes in the lid and mount the lid to the support.

Check Rockler.com for updates. If you have further questions, please contact our Technical Support Department at 1-800-260-9663 or support@rockler.com

