



Hinges can be used in either inset, full overlay or twin door applications. Door thickness can be 5/8" to 3/4".

1. Orient the hinge correctly for your application. Using the hinge or the reference dimensions shown, mark the screw locations on the cabinet wall and door back.
2. Drill stopped pilot holes for the included screws in the cabinet wall and mount the hinges.
3. Drill stopped pilot holes for the screws in the door and mount the door to the hinges.
4. Adjust as necessary to align door to cabinet.
5. Tighten all screws.

Check Rockler.com for updates. If you have further questions, please contact our Technical Support Department at 1-800-260-9663 or support@rockler.com

