

- Using the hinge or the reference dimensions shown, mark the screw locations on the cabinet wall and door back.

Note: For fast, easy and accurate location and drilling, we recommend using the JIG IT[®] Hinge Plate Template for 175° Hinges (59459, sold separately) and a Rockler/Insty-Drive #6 Self-Centering Bit (68991, sold separately).

- Drill stopped pilot holes for the included screws and mount the hinges to the cabinet.
- Drill stopped pilot holes for the door screws and mount the door to the hinges.

- Adjust as necessary to align door to cabinet. Tighten all screws.

Check Rockler.com for updates. If you have further questions, please contact our Technical Support Department at 1-800-260-9663 or support@rockler.com

