



1. Using the hinge or the reference dimensions shown, mark the screw locations on the inside back of the box or cabinet and the underside of the lid.
2. Drill stopped pilot holes for the box/cabinet screws and mount the hinges to the box.
Note: To avoid binding, use the #6 x 5/8" flat-head screws in the holes toward the center of the hinge and the #7 x 5/8" round-head screws in the outside holes.
3. Drill the pilot holes for the lid screws and attach the lid to the hinges.
4. Adjust as necessary to align lid to box or cabinet. Tighten all screws.

Check Rockler.com for updates. If you have further questions, please contact our Technical Support Department at 1-800-260-9663 or support@rockler.com